


BASIC INSTRUCTIONS TO SET UP YOUR **QUARTZ** CUCKOO CLOCK

1. Open up the back panel of the clock and insert the size C batteries into the movement. Replace the back panel.
2. Hang the clock on the wall on a screw that is at a 45 degree angle, so the clock sits flush on the wall (a). **(Do not use a hook or a nail)**
3. Remove the gold wire holding the bag of ornamental chains (b) and hang your weights onto the hooks (c). Hang your pendulum onto the pendulum hanger underneath the clock (d).
4. To set the time, move the minute hand in a clockwise direction until you reach the correct time, allowing the cuckoo to strike each hour. Alternatively, you can silence the cuckoo whilst setting the time, by switching the cuckoo/music to "Off" using the switch on the side of the clock (e) and moving the minute hand freely without having to wait for the cuckoo each hour. You will hear it click inside as it goes past each hour.
5. There is a light sensor on the clock usually above the number XII, which automatically silences the cuckoo at night when the room is dark.
6. Enjoy your cuckoo clock and the good luck blessing it will bring to your home!



TROUBLESHOOTING:

- If the time on the clock does not correspond to the number of cuckoo calls, proceed as follows:

eg. If cuckoo calls twice } move the hour hand to the numeral 2.

eg. If cuckoo calls 9 times } move the hour hand to the numeral 9.

From here, you can then move the minute hand in a clockwise direction until the correct time is reached.

- If the bird's door does not open or the clock is running slow, the batteries must be replaced. Remove the batteries, **set the hands to 12:05**, and insert new batteries. The first cuckoo will then be 1 O'Clock. Follow step 4 to set the time.

For further information and instructional videos, check out the FAQ section on our website.

www.clocks.com.au